



Technical Support



www.scottoiler.com technical@scottoiler.com +44(0)141 955 1100

SA-0620 KTM 690 LC4, 950 & 990 LC8 dispenser adapter

Parts List:

M10 x 16 screw



10mm Dispenser Plate



7mm spacer

The enclosed parts allow for fitment of either a Scottoil eSystem or vSystem to KTM street models.

For model specific installation guides with photographs, please visit www.scottoiler.com

Dispenser Assembly

1. Fit the M10 bolt together with the 10mm dispenser plate and the 7mm aluminium spacer.

Secure the M10 assembly on the swinging arm.

Note: On 690 Supermoto and 690 Duke models, the 7mm aluminium spacer is not required.

Note: RC8 models do not require this adapter, simply fit the small dispenser plate from the Scottoil kit between the bobbin and swingarm.

2. Secure the dispenser assembly to the dispenser plate by clamping around the black nylon sleeve using the jubilee clip. Carefully position the nib between 6 and 8 o'clock, on the outside face of the rear sprocket with the slash cut facing away from the sprocket. Take care to avoid the sprocket bolts.

3. Follow the instructions from your Scottoil kit and route the delivery tubing from the dispenser to the reservoir (RMV or REP). If fitting a vSystem connect tubing to RMV, if fitting an eSystem, the delivery tubing must be primed before inserting the checkvalve, as described in the eSystem instructions. Follow relevant kit instructions from here on.

